

ON/OFF DIRECT


NEUTRAL



EARTH



LINE

ON/OFF DIRECT/INDIRECT
(COMMON NEUTRAL)

LINE 1




NEUTRAL



EARTH



LINE 2

ON/OFF DIRECT/INDIRECT
(SEPERATE NEUTRAL)

LINE 1



NEUTRAL




EARTH



NEUTRAL 2



LINE 2



DALI DIRECT

LINE 1



NEUTRAL




EARTH



DA



DA



PUSH BUTTON

LINE 1



NEUTRAL




EARTH



PUSH BUTTON



PUSH BUTTON



1-10V DIRECT

LINE 1



NEUTRAL



EARTH



1-10V +



1-10V -

